
OA Flooring FP3000 / Raised Access Flooring • FUKUVI





Installation





Eliminate extreme irregularities








(4)Secure the leg to the floor

1. Align the direction of separator with the reference line 2. Press legs against the floor until the adhesive squeezes out



$(\mathbf{5})$ Place the panel on the leg and fix it

Locking screw 1.Place the panel while hooking it on the protrusion of legs 2. If necessary, cut the panel for the wall Washer 3.Secure with screws Protrusion Separator

•Construction example <OA Flooring FP3000>



■OFFICE (KANAGAWA·NARA/JAPAN)









